

## Eka készülékek csövezése

Készüléktípus	Csövezés				
Eka 2+1	<b>P</b> AS4120	<b>S</b> PP430	<b>V</b> V430		
Super Eka	<b>P</b> AK1	<b>S</b> HP4101	<b>V</b> PP4101	<b>N</b> DS4100	<b>O</b> PV4200
Reform	<b>P</b> AF7	<b>S</b> AL1	<b>V</b> AZ1		
ABC Super	<b>P</b> AK2	<b>S</b> AF7	<b>V</b> AL1	<b>N</b> DS4100	<b>O</b> AZ1
218	<b>M</b> AF7	<b>T</b> AL4	<b>V</b> AZ1		
218 U	<b>M</b> CF7	<b>T</b> CL4	<b>V</b> CY2	<b>I</b> <sup>200 RI</sup> 220 V.-nál	
528	<b>D</b> AF3	<b>I</b> ACH1	<b>J</b> AF3	<b>T</b> AB2	<b>S</b> AF7
	<b>R</b> AL5	<b>P</b> EZ4	<b>B</b> ME4		
219	<b>M</b> EF6	<b>T</b> EL3	<b>V</b> EZ2		
219 U	<b>M</b> CF7	<b>T</b> CL4	<b>V</b> CY2		
319	<b>P</b> ACH1	<b>S</b> EF9	<b>V</b> EBL1	<b>I</b> EZ3	
2140	<b>M</b> EF6	<b>T</b> EL3	<b>V</b> EZ2		
2140 U	<b>M</b> CF7	<b>T</b> CL4	<b>V</b> CY2	<b>I</b> <sup>200 RI</sup> 220 V.-nál	
4140	<b>P</b> ECH3	<b>S</b> EF9	<b>V</b> EL3	<b>I</b> EBC3	<b>N</b> EZ3
413	<b>S</b> ECH4	<b>V</b> ECL11	<b>O</b> EZ2		
413 U	<b>R</b> ECH3	<b>T</b> EF6	<b>N</b> CL4	<b>I</b> CY2	<b>V</b> <sup>200 RI</sup> 220 V.-nál
413 G	<b>S</b> ECH4	<b>V</b> ECL11	<b>O</b> EZ2		
414	<b>P</b> ECH3	<b>S</b> EBF2	<b>I</b> ECL11	<b>N</b> EZ3	
424 T	<b>R</b> DCH21	<b>I</b> DF21	<b>O</b> DBC21	<b>V</b> DLL21	
424 U	<b>R</b> ECH3	<b>T</b> EF6	<b>N</b> CL4	<b>I</b> CY2	<b>V</b> <sup>200 RI</sup> 220 V.-nál
425	<b>R</b> ECH3	<b>T</b> EBF2	<b>O</b> ECL11	<b>V</b> EZ3	<b>B</b> EM4
425G	<b>R</b> ECH3	<b>T</b> EBF2	<b>O</b> ECL11	<b>V</b> EZ3	<b>B</b> EM4
427	<b>P</b> ECH3	<b>M</b> ECH3	<b>S</b> EF9	<b>T</b> EL3	<b>N</b> EBF2
	<b>V</b> EZ3	<b>B</b> EM4			